



All Elbows to be Schedule 80 Long Sweep (36")

**NOTES:**

1. Customer responsibilities:
  - ◆ Digging all trenches
  - ◆ Installing conduit
  - ◆ Installing necessary concrete pad per VEC specs
2. Top of concrete pad should extend above the finished grade 2" to 3".
3. Top of concrete pad must be level.
4. Back fill under concrete pad must be thoroughly compacted.
5. Do not back fill with rocks or debris.
6. VEC representative must inspect work before back filling can begin.
7. Marking tape (furnished by VEC) should be placed 12" above top of conduit.
8. 3" conduit may be required for 400 Amp service as directed by VEC Engineer.

|   |   |                 |
|---|---|-----------------|
|  | Installation Guidelines<br>Underground Service with<br>Underground Transformer - Concrete Pad |                 |
|   | Revised<br>08/18/14   | Drawn By<br>CKD |